


Instructions

Pressure Controls KP 21


060R9410

Ambient temperatures




Caution: Do not mount the control in a position where dirt, sediment or oil will affect the operation of the control.

Test pressure (p_{test})




060R9410

Enclosure




CAUTION: The mounting panel must be plane to avoid damage of control

Low pressure (LP) side setting



CUT-IN minus DIFFERENTIAL equals CUT-OUT


High pressure (HP) side setting



CUT-OUT minus DIFFERENTIAL equals CUT-IN

LP range

Increase 360°CW (+)
Decrease 360°CCW (-)



DANFOSS
A60-721.16



CAUTION:

Disconnect power supply before wiring connections are made or service to avoid possible electrical shock or damage to equipment.
Do never touch live parts with your fingers or with any tool.

Contact load

Alternating current:

AC 1: 16 A, 400 V

AC 3: 16 A, 400 V


AC15: 10A, 400 V

Max. starting current (L.R.): 112 A, 400 V

Direct current:

DC13: 12 W, 220 V control current

Function



Danfoss
60-4893.11

Note!

(M) = Load


(X) = Signal option

↕ = Bellows movement on pressure rise

↕ = Bellows movement on pressure drop

Controls with low pressure (LP) and high pressure (HP) signal

Terminal block



DANFOSS
A60-672.14

CAUTION: Use terminal screws furnished in the contact block.
Use tightening torque (20 lb.) in 2.3 Nm.
Use copper wire only.

Low pressure (LP) side:

A-C close on LP rise

A-C open on LP drop

High pressure (HP) side.

A-C open on HP rise

A-C close on HP drop

LP signal option:

A-B close on LP drop

HP signal option

A-D close on HP rise